

Requirements for an error-free *hyperMILL*® installation Windows 10

To ensure your *hyperMILL*® installation runs smoothly, please note the following points:

1. Your hard drive should have at least 7 GB of free storage space.
2. Are your operating system and CAD platform supported by *hyperMILL*®?
Please check this in the release notes of the [Readme-en.pdf](#) file under 'Platforms and interfaces'.
3. Log on as local administrator.
4. Stop your antivirus software's scanning process.

OPEN MIND also recommends that you exclude the following directories, file types, processes and services from your virus scan:

Directories		
NC file		Specified by the user
Postprocessor		Specified by the user
CAD file		Specified by the user
<i>hyperMILL</i> ® installation		Default path: C:\Programs\OPEN MIND\
General working space		<i>hyperMILL</i> ® settings -> Application -> Default paths
Project		<i>hyperMILL</i> ® settings -> Document -> Directories
Licensing software		C:\Program Files (x86)\CodeMeter
OPEN MIND Roaming		C:\Users\User Name\AppData\Roaming\OPEN MIND
OPEN MIND temp		C:\Users\User Name\AppData\Local\Temp
OM PrgramData		C:\ProgramData\OPEN MIND

File types			
*.3df	*.h	*.oma	
*.def	*.hmc	*.omx	
	*.hmrep	*.tmpof	
	*.hvz	*.pof	
	*.nc	*.vis	

*These file types are trusted as they are generated exclusively by *hyperMILL*®.*

Processes			
CodeMeter.exe	hmc.exe	omCheck_x64.exe	
cycrunx64.exe	LicenseManager.exe	omHV.exe	
		omHV64.exe	
		omToolDBW32.exe	
		omToolDBX64.exe	

Services	
	Service of CodeMeter.exe

Please get your IT experts to set up your antivirus software according to the information provided.